



ZeoFiber

DE REPLACEMENT / FILTER MEDIA & FILTER AID

ZeoFiber gives crystal clear water in DE, cartridge, and sand filters. The non-abrasive and biodegradable pure cellulose fibers in ZeoFiber are safe for you and the environment. The cellulose fibers in ZeoFiber weave together to trap small particles and give clearer water than other filter media.

DE OR PRE-COAT FILTERS: CONVERSION TO ZEOFIBER

Step 1. Thoroughly clean filter before converting from DE to ZeoFiber.

Step 2. With your filter area and the below table, calculate the amount of ZeoFiber for your filter.

Filter Size Effective Filtration Area (Square feet)	ups of ZeoFiber (Included 8 fluid ounce measuring cup)
24	6
36	9
48	12
60	15
72	18

(A normal DE scoop holds about 5 times more than the measuring cup included in the package.)

Step 3. Slowly add ZeoFiber to skimmer with the pump running.

Note: ZeoFiber removes more dirt that DE, during the first few filter cycles after converting to ZeoFiber. These cycles may be shorter than future filter cycles.

ROUTINE BACKWASHING

Step 1. When the filter pressure increases about 10 pounds above the starting pressure, backwash until water runs clear.

Step 2. Place the filter in rinse mode for 15 seconds. Use filter mode for 15 seconds, if rinse mode is not available on your filter.

Step 3. Repeat Step 1. and 2 two more times.

Step 4. In the filter mode and with the pump running, recharge your filter.

Phosphate removers and sequestering agents may cause pressure to build up more quickly and shorten

INSTRUCTIONS

the filter cycle time. When clarifiers and coagulants are used, the filter should be backwashed within a few hours after these materials are filtered.

NSF/ANSI Standard 50 certification testing showed that 3 pounds of ZeoFiber is equivalent to more than 25 pounds of DE. Less ZeoFiber was needed to charge the filter than DE, and the smaller ZeoFiber filter charge lasted longer.

CARTRIDGE FILTERS

For longer cartridge life and finer filtration, add ZeoFiber as a filter aid to your cartridge filter. Dirty cartridges are easier to clean when ZeoFiber is used.

USING ZEOFIBER

Step 1. Clean your cartridge filter.

Step 2. With your cartridge area and the below table, find or calculate the amount of ZeoFiber for your filter.

Cartridge Size Area (Square feet)	Cups of ZeoFiber (Included 8 fluid ounce measuring cup)
25	2
50	4
100	8
250	20

Step 3. Slowly add ZeoFiber to skimmer or pump return with the pump running. The filter pressure should increase about 1 pound (psi).

Step 4. When the filter pressure increases about 10 pounds, clean the cartridge filter per the manufacturer's instructions.

SAND FILTER
By adding ZeoFiber to your sand filter, smaller dirt particle are removed, and water clarity is quickly improved.

Step 1. Backwash until the water flow is clear and return filter to filter mode.

Step 2. Slowly add ZeoFiber to the skimmer or the pump return while the pump is running until the filter pressure increases one pound.

With your filter diameter and the below table, find or calculate the maximum amount of ZeoFiber for your filter.

Sand Filter Diameter (Inches)	Cups of ZeoFiber (Included 8 fluid ounce measuring cup)
12	1
18	2
24	4
30	6
36	9
42	13
48	16

CAUTION: When water is very dirty, the filter pressure will increase quickly. The filter pressure should be checked frequently.

Step 3. Backwash after 24 hours or sooner if the pressure increases about 10 pounds.

Step 4. Repeat Steps 1 through 3, until the water is completely clear water.

ZEO, Inc.
P.O. Box 2353
McKinney, Texas 75070
www.zeoinc.com



800-530-8283
972-542-0053
972-542-0211 FAX
zeosand@zeoinc.com



3 lbs (1.3 kgs) Net Weight

Drinking: 61 Health Effects



Filter Media

Rec Water: 50 Health Effects

- ✓ Easy to Use
- ✓ Biodegradable
- ✓ Safe & Natural
- ✓ Crystal Clear Water

3 Pounds
Replace Over
25 Pounds
of DE

Meets or Exceeds
NSF/ANSI Standards:

Filter Media and Filter Aid

DE REPLACEMENT

ZeoFiber

